


fuel


2300 mA lithium polymer battery for the **BlackBerry 8900**

instructions



cm case-mate®

components diagram



- a) 180-degree ratcheting belt clip
 - b) micro usb connector
 - c) LED indicator (blue)
 - d) power on/off button
 - e) terminal connectors
- * device faces outward for easy screen visibility and use.

features

- **talk time:** up to 7 additional hours beyond standard BlackBerry 8900 battery life
- **standby time:** up to 20 additional days beyond standard BlackBerry 8900 battery life
- power on/off button (d) allows activation of the fuel battery pack as needed.
- rechargeable through a standard micro usb cable (included)
- fully ratcheting 180-degree belt clip (a)
- easy slide in/out access to your BlackBerry 8900

specifications

the case-mate® fuel comes with a built-in, safety tested, advanced lithium polymer high capacity rechargeable battery that increases your BlackBerry 8900 standard battery life by 1.6 times the normal amount.

- **battery capacity:** up to 2300mA
- **battery charging current:** up to 450mA
- **battery max discharging current:** 2A
- **power consumption:** 4.8v/2.5w
- **battery operational temperature range:** 5°F to 122°F or -15°C to 50°C

led indicators

normal use:

- **three solid blue lights** 100%
- **first light blinking** 80%
- **2 solid blue lights** 60%
- **1 solid blue light** 40%
- **1 light blinking** 10%

while charging:

- **3 solid blue lights (c):** charge complete
- **2 solid blue lights (c):** 50% complete
- **1 solid blue light (c):** charging